

1997 Talbert Flatbed

Cut out old kingpin, prep kingpin plate, weld new kingpin bolster into new Kingpin overlay plate & paint

Cut out all 4 rear suspension airbag mounting plates, prep airbag support cross members. Prep, weld and paint new supporting cross members. Drill new location holes for airbag stud mounts, Install new airbags, new airlines & fittings

Remove and replace right rear wheel seal, install new wheel bearings, new wheel seal, spindle nuts. Install new hubcap, replace brake shoes, adjust all brakes and tires

Check and replace all lights and replace to working order, new pigtail installed. Complete service and grease

Labor 918.75

Parts 1,417.10

Total 2,335.85